


Quick Start Guide

Miss World Wireless Neckband Earphones





I. Important - Warnings and Safety Instructions

- 1. While placing the earphone in your ears, please keep the volume down and then gradually adjust the volume to an appropriate, comfortable level.
- 2. Prolonged use at high volumes might damage your hearing.
- 3. Focus on your safety and of others. We recommend not to listen music while riding or driving, or at any time when the inability to hear surrounding sounds may present a danger to yourself or others.
- 4. If you experience a warm sensation or loss of audio, do remove and disconnect immediately.
- 5. Do not place the NeckBand near heat sources such as fire, radiators, stoves, light candles and other apparatus that produces heat.
- 6. Use only those accessories supplied by FINGERS.
- 7. Unplug the NeckBand once it is fully charged, when unused for long periods of time or during lightning/thunderstorms.
- 8. It is recommended to refer all servicing to qualified personnel. Servicing is required when the device has been damaged in any way. Any evidence of any attempt to open and/or alter the device, including any scratch, peeling, puncturing, or removal of any of the labels, will void the Limited Warranty.

II. Care and Maintenance


- 1. Switch off the device before cleaning it.
- 2. Use soft, damp cloth to clean the surface.
- 3. Do not use any chemicals, solvents, or cleaning solutions containing alcohol, ammonia or abrasives.
- 4. Do not allow any liquid to enter into any of the openings.

III. Charging



- A red light indicates that it is in charging mode. Once it is completely charged, the LED glow changes to blue.

IV. On-board Controls



Function What to do

1. Volume Down/Previous Track
Decrease VolumeLong Press
Previous TrackShort Press
Reject Incoming CallDouble Press

2. MFB

On-OffLong Press
Play/Pause Short Press
Voice Assistance Press for 2 seconds
Navigate between modes Triple Press

Manage Calls

2

Receive call	Short Press
End call	Again Short Press
Redial Last called number	Double Press

3. Volume Up/Next Track Increase Volume Long Press Next Track......Short Press

V. BT Mode

- Switch on the NeckBand till the LED indicator starts flashing in blue and red alternately, signifying that it is ready to pair a device.



- As it flashes blue and red alternately, make sure that Bluetooth is enabled on your device. Find the device list and select FINGERS Miss World.
- The indicator flashes in blue for a moment, a sound connected is heard and it is ready to play.
- Repeat above steps to pair another device.

VI. MicroSD Mode

- Insert the Micro SD card in the provided port.
- You can then play your favourite tracks directly from the Micro SD Card

VII. Product Specifications

Wireless Protocol	BT v5.0+EDR
Input Power Rating	5 V, 500 mA
Driver unit	Φ 10 mm
Effective Frequency Range	2.402 GHz ~ 2.480 GHz
Effective Range	Up to 10 meters
Battery	180 mAh
Charging Time	Up to 2 hours
Playback Time ¹	Up to 13 hours
TalkTime ¹	Up to 10 hours
Standby Time	Up to 165 hours
Playback Options	BT I MicroSD
Dimensions	135mm (L) x 184mm (W) x 18mm (H)
Weight	35 g
Colours	Blush Pink I Dreamy Blue I Midnight Black

Supplementary Features

- Sweat Resistant²
- Voice Assistant Support (on default Phone OS)

VIII. In the box

- 1 x FINGERS Miss World
- 1 x USB Charging Cable
- 2 sets of Extra Ear-gels
- 1 N x Quick Start Guide

Stay connected with us

@fingers.co.in @@FingersIndia

Customer Service

- 1-year warranty
- Support email: customer.care@fingers.co.in
- 022-4938 7600: Mon Fri (9.30 am to 6.30 pm)

For further information, please visit www.fingers.co.in

¹Tested under ideal conditions and in BT playback mode. Playback time may vary depending on usage, playback mode and volume levels.


- ²Tested under limited conditions. Do not immerse it in liquid.
- Images shown may vary from actual product.
- · Specifications, features and appearance are subject to change without notice. • All logos, brands, trademarks and product names are properties of their respective owners. • Product warranty is governed by warranty terms mentioned on www.fingers.co.in · This product falls



4



6



5